



★ **FOR BEST RESULTS**

- Use Sketch Wizard unit on a flat surface in a brightly lit room.
- Use care near eyepiece & panel. Slight bumps may knock photos or 3D objects off of yellow shelf.
- Use adhesive tape or mounting putty (not included) to hold photos, printed scenes, 3-D objects in place if base moves.
- If you need to stop & start again later, keep art/object & paper position the same. Moving either will put the image in a different place on the paper.
- Store pencils in the space behind the yellow shelf to keep them handy & organized.


SET IT UP!




Pull eyepiece panel to upright position & **CLICK** into place.



Unfold base & drop support legs to raise the back panel.



Firmly pull **BOTH LENSES** away from the lens holder & snap into position shown.



Firmly pull the top lens up until it snaps into position shown.



Place a sheet of white paper on base. Insert corners under tabs to hold it in place.

NOW YOU'RE READY TO DRAW!

WHAT DO YOU WANT TO DRAW?

PICK ONE...



Flat Art

Try copying from a printed scene, photo or digital tablet image placed on back panel shelf. (top lens should be in **DOWN** position)

OR



Small Objects

Pull down yellow shelf for small objects up to 3 inches high. (top lens should be in **UP** position)

OR




Large Objects

Fold legs under & lay back panel flat for larger objects up to 6 inches high. (top lens should be in **UP** position)

NOW DRAW IT!




Hold a pencil & place your hand on paper. **LOOK STRAIGHT AHEAD** through the eyepiece with one eye.



Once you can see your hand, pencil & object through the eyepiece, you can start tracing.

TIPS



If you need to stop & start again later, keep art/object & paper position the same. **Moving either will put the image in a different place on the paper.**



To use the base for coloring your artwork: pull the tab on the base, push the buttons on the panel & slide panel out of the base.



Crayola

**SKETCH
WIZARD™**
DRAW ANYTHING!™

8+

Contents



Base




Eyepiece Panel




6 Short Colored Pencils




Graphite Pencil



5 Sheets Blank Paper




5 Printed Scenes



Store Your Sketch Wizard

1. Place pencils in space behind yellow shelf to keep them handy.
2. Fold legs flat & pull back panel forward to rest on the base.
3. Re-insert eyepiece panel & move lenses back to flat position.
4. Pull tab & press eyepiece panel buttons to lower panel to flat position.



SAFETY INFORMATION



Conforms to ASTM D 4236.
All Crayola art materials are nontoxic.

WARNING! Not suitable for children under 36 months due to small parts which may cause a choking hazard if swallowed. Crayola Pencils are certified AP

WASHING & CARE INFORMATION

FOR BEST RESULTS: To sharpen pencils, use a hand-held sharpener.

QUALITY GUARANTEE

We guarantee the quality of all Crayola products. If this product does not perform properly, please contact us.

In the U.S.A. and Canada, call **1-800-CRAYOLA (800-272-9652)**, weekdays 9 AM-4 PM ET.

In Europe, call **+33 (0) 1 41 06 54 54**, weekdays 9 AM-5 PM local time.

In the UK, call **01702 208170**, weekdays 9 AM-5 PM local time.

In Mexico, call **01800 71 78 222**, weekdays 9 AM-5 PM local time.

In Australia, call Crayola AU at **1-800-657-353**, weekdays 9 AM-4 PM AEST.

Contents and colors may vary. Keep instructions for future reference.



A  Hallmark Company

©2014 Crayola, Easton, PA 18044-0431.

Distributed in Australia by Crayola (Australia) Pty. Ltd.
Imported by Binney & Smith (Europe) Ltd., Bedford Heights,
Manton Lane, Bedford, MK41 7PH, England.



crayola.com

04-6820-0-150